Maven is Java based tool, so the very first requirement is to have JDK installed on your machine.

System Requirement

Java 1.5 or above

Step 1 - verify Java installation on your machine

java -version

Step 2: Set JAVA environment

Windows:

JAVA_HOME=C:\Program Files\Java\jdk1.8.0_60 PATH=%JAVA_HOME%\bin

MAC:

Document Uploaded

Step 3: Download Maven archive

Download Maven 2.2.1 from http://maven.apache.org/download.html Zip file for windows tar.gz file for MAC

Step 4: Extract the Maven archive

Extract the archive, to the directory you wish to install Maven 3.3.3. The subdirectory apache-maven-2.2.1 will be created from the archive.

Recommended Location:

Windows: C:\Program Files\Apache\apache-maven-3.3.3

MAC: /usr/local/apache-maven

Step 5: Set Maven environment variables

Windows:

Set the environment variables using system properties.

M2_HOME= C:\Program Files\Apache\apache-maven-3.3.3

M2=%M2_HOME%\bin

MAVEN_OPTS=-Xms256m -Xmx512m

MAC:

Open command terminal and set environment variables.

export M2_HOME=/usr/local/apache-maven/apache-maven-2.2.1 export M2=\$M2_HOME/bin export MAVEN_OPTS=-Xms256m -Xmx512m

Step 6: Add Maven bin directory location to system path

Windows: Append the string; %M2% to the end of the system variable,

Path.

MAC: export PATH=\$M2:\$PATH

Step 8: Verify Maven installation

mvn --version